

# Visual Training

## Replacing a Printer Ribbon in a TranScan® Cab/Trailer



Open the cover to enable access to the printer mechanism.





Remove the old ribbon cartridge by pressing the left hand end of the cartridge (marked PUSH).



Load the new ribbon with the paper feeding between the cartridge and exposed ribbon. Then replace the printer cover.



Press either of the blue print buttons (  or  ) to operate the printer.

Ensure that the cartridge is located correctly and gives a clear print out.